
Contents

Product Overview	2
Product Introduction	2
Accessories	2
Product Connection	3
Driver	4
Install Driver	4
Driver Interface Preview	5
Keydial Setting	7
Driver Setting	8
Function Setting	12
Keys Function Setting	12
Dail Function Setting	16
Specifications	19

Product Overview

Product Introduction



Thanks for choosing HUIION mini Keydial KD100. This is a first generation of professional mini keyboard, which can greatly improve your work efficiency of painting and creation, and full of fun. You can freely define the function of the button, which brings you a real shock experience.

To give you a better understanding and using of your keyboard, please read this user manual carefully. The user manual only shows the information under Windows, unless otherwise specified, this information applies to both Windows and Mac systems.

Note: The pictures in the User Manual are for reference only.

Accessories

After unboxing your package, make sure that you have the following items:

Mini Keydial*1


USB Cable*1

Wireless Receiver*1

Quick Start Guide*1



USB-C Cable



Receiver



Quick Start Guide


Product Connection

The product supports two ways of wired connection and wireless connection, please choose these ways to connect according to the usage.

1. Wired Connection

Connect the tablet to your computer with USB cable. Please follow the steps below:


1. Take out the USB cable from the package, then connect Keydial to your computer.
2. Please download the Keydial Driver from our website: [Driver-KD100](#). Besides, you don't need to download the driver anymore if you already installed the other display or tablet driver(V15). They can work together with one driver.
3. Open the driver interface, the device picture will be displayed on the interface, indicating that the tablet is successfully connected to the computer. You can start use the tablet.



2. Wireless connection

Please follow the steps below:


1. Insert the wireless receiver to your computer.
2. Switch the power button on to power on the Keydial.
3. Not using 15 mins, the tablet will enter sleep mode. In this case, you need to switch the power button on again to wake the tablet up.



3. LED Light

You can judge the working status of the product by observing the color of the light.

1. Blue light: Working
2. Flash red light: Low battery
3. Red light: Charging
4. Green light: Charged
5. Flash blue light: Standby
6. Light off: Off state



Driver

Install Driver

Please download the driver from our website: [Driver-KD100](#)

Note:


1. You don't need to download the driver anymore if you already installed the other display

or tablet driver(V15). They can work together with one driver.


2. Before installing driver, please close all graphic software and antivirus program.
3. Please make sure your computer OS are as following: Windows 7 or later, macOS 10.12 or later.
4. Run the tablet driver program and complete the installation according to the instruction.


After the download is successful, double-click to open the driver, Connect the device to your computer.

If the connection fails, please reconnect the computer to the device, or restart the driver or computer.



Driver Interface Preview





1. KeyDial

Keydial function setting interface, the users can set the KeyDial function on this interface, such as Press Key and Dial.

[See Section](#)

2. Store

Huion Store, where you can get the latest information about the product such as its FAQ or sales promotion. Additionally, you can also purchase other products or accessories on Huion Store.

3. Add Programs

You can customize different functions on the current device for different programs. When select All programs, the setting of the device is valid for every program. By clicking Add a Program from the drop-down list, you can set the functions for a specific program and hence have unique settings for different programs. After that, when launching a

specific program, the Driver will automatically recognize it and the setting features will change to its corresponding one.

4. Setting


The users can set the Driver function on this interface. About Device Information, Backup Setting, General Setting and Driver Update.

[See Section](#)

5. Switch between Devices

Driver can support the connection to two digital drawing devices at the same time. When these devices are sharing the same Driver with the current device, users can customize the settings of the devices by switching the Driver interface to the corresponding one.

Keydial Setting



1. Brightness of LED

Click to adjust the brightness of the LED light from level 1 to level 5, among which level 1

represents the darkest and level 5 represents the brightest.

2. Dial Function Setting

You can select Customize mode, Radial mode, or Off mode under the Features of Dial. In Customize mode, you can customize the features of the Dial.

[See Section](#)

3. Sleep Time

By default, the device will turn into sleep mode in 30 minutes when you are not using, but you can also set the sleep time to 1h, 1.5h or 2h according to your usage habits.

4. Restore Default

Click to restore all the default settings. Including LED light brightness, sleep time, Keys function setting, Dial function setting, interface color and so on.

5. Keys Function Setting


You can customize the functions of these buttons according to your own habit.

[See Section](#)

Driver Setting


1. Device

You can view product information.



2. Backup

The Driver can import and export your custom settings, which helps to avoid repeated settings when launching a different program.




3. General Setting

[1] Language: Click the drop down menu to select a language.

[2] Color: You can select the color of the Driver interface among Dark, Blue, and Light according to your preference.


[3] Start Menu: Click to enable or disable AutoStart, New Message Alert, Automatic Updates.

[4] Hotkey: A hotkey can be used to call out the Driver interface quickly, you can set one according to your usage habits.



4. About

Users can check the Driver version number here. Click Check for Updates to view the latest Driver version and then follow the prompts to update the Driver if needed.



Function Setting


Keys Function Setting

Press Key

You can customize the functions of these buttons according to your own habits, and you can uncheck "Enable press keys" in the lower left corner to turn off the button function.

Place the cursor on a key to check its default value. Click the key for a pop-up dialog box and then set the function.

You can enter a name for the keystroke, then select the property of the keystroke and customize the function.



1. Keyboard Key

Click on the input box above and enter a valid key combination to create a shortcut. For example "Ctrl+A", "Ctrl+Z", and so on.

Enter a Name for the Keystroke

- ☒ Keyboard Key
- ☐ Mouse Key
- ☐ Run Program
- ☐ System Application
- ☐ Multimedia
- ☐ Settings Preview
- ☐ Quick Menu
- ☐ None

Enter the Keystroke

None

Click on the input box above and enter a valid key combination to create a shortcut


2. Mouse Key

Select the function of a Mouse or Wheel. Please see the picture below for detailed functions.

Mouse: Left Button, Right Button, Middle Button.

Wheel: Wheel Forward, Wheel Backward.


Double-Left Click.



The screenshot shows a dark-themed dialog box titled "Enter a Name for the Keystroke". It is divided into two columns. The left column contains a list of options: "Keyboard Key", "Mouse Key" (which is selected with a blue dot), "Run Program", "System Application", "Multimedia", "Settings Preview", "Quick Menu", and "None". The right column contains a list of mouse and wheel actions: "Mouse Left Button", "Mouse Right Button", "Mouse Middle Button", "Double-Left Click", "Wheel Forward", and "Wheel Backward". To the right of these actions are four checkboxes for modifier keys: "Ctrl", "Alt", "Shift", and "Win".

3. Run Program

Browse and select a program that you want to launch quickly. After the setting, you can launch that program with just a single press.



The screenshot shows a dark-themed dialog box titled "Enter a Name for the Keystroke". It is divided into two columns. The left column contains a list of options: "Keyboard Key", "Mouse Key", "Run Program" (which is selected with a blue dot), "System Application", "Multimedia", "Settings Preview", "Quick Menu", and "None". The right column is titled "Select a Program" and contains a text input field labeled "Program Path". Below the input field is a text instruction: "Click on the 'Browse' to select a file." At the bottom of the right column is a blue button labeled "Browse".

4. System Application

You can apply these functions to press keys: Lock the Screen, Sleep, Power Off, Show/Hide Desktop, Task View, Start Menu, and Calculator.

Enter a Name for the Keystroke	
<input type="radio"/> Keyboard Key	<input type="radio"/> Lock the Screen
<input type="radio"/> Mouse Key	<input type="radio"/> Sleep
<input type="radio"/> Run Program	<input type="radio"/> Power Off
<input checked="" type="radio"/> System Application	<input type="radio"/> Show/Hide Desktop
<input type="radio"/> Multimedia	<input type="radio"/> Task View
<input type="radio"/> Settings Preview	<input type="radio"/> Start Menu
<input type="radio"/> Quick Menu	<input type="radio"/> Calculator
<input type="radio"/> None	


5. Multimedia

You can apply these functions to press keys: Previous Song, Next Song, Play/Pause, Volume up, Volume down, and Muted.

Enter a Name for the Keystroke	
<input type="radio"/> Keyboard Key	<input type="radio"/> Previous Song
<input type="radio"/> Mouse Key	<input type="radio"/> Next Song
<input type="radio"/> Run Program	<input type="radio"/> Play/Pause
<input type="radio"/> System Application	<input type="radio"/> Volume Up
<input checked="" type="radio"/> Multimedia	<input type="radio"/> Volume Down
<input type="radio"/> Settings Preview	<input type="radio"/> Muted
<input type="radio"/> Quick Menu	
<input type="radio"/> None	

6. Settings Preview

Pick it up and you can use the key to pull up the preview setting function.




Enter a Name for the Keystroke

- ☐ Keyboard Key
- ☐ Mouse Key
- ☐ Run Program
- ☐ System Application
- ☐ Multimedia
- ☒ Settings Preview
- ☐ Quick Menu
- ☐ None

7. Quick Menu

Pick it up and you can use the key to pull up the Quick Menu.



Enter a Name for the Keystroke

- ☐ Keyboard Key
- ☐ Mouse Key
- ☐ Run Program
- ☐ System Application
- ☐ Multimedia
- ☐ Settings Preview
- ☒ Quick Menu
- ☐ None

Quick Menu

Different quick menus for different a...

Customize

8. None


When select None, the keys will have no function.

Dail Function Setting

You can customize the features of the Dial, and you can uncheck "Enable Dial" in the lower left corner to turn off the Dial function.

Click the Dial for a pop-up box where you can see the three groups of current settings and to modify them.

There are four properties for the Dial, which are Default, Multimedia, Customize Function, and None.



1. Default Features

You can zoom in/out on canvas, Adjust Brush Size, Scroll Up/Down.

Enetr a Name for the Keystroke

☒ Default

☐ Multimedia

☐ Customize the Feature

☐ None

☒ Zoom In/Out

☐ Adjust Brush Size

☐ Scroll Up/Down

2. Multimedia

To realize the functions such as previous song, next song, play/pause, volume up, volume down.

Enetr a Name for the Keystroke

☐ Default

☒ Multimedia

☐ Customize the Feature

☐ None


☒ Previous Song/Next Song

☐ Volume Settings

3. Customize Features

Input the features under rotate right / rotate left.

After the setting, you can rotate the Dial to realize corresponding features.



4. None

When select None, the keys will have no function.

Specifications

Here are the product specifications for you to learn more about the KeyDial. If you have any questions, please feel free to contact us.

The following data will vary in different usage environments and are for reference only.

Appearance

Color:	Black
Dimension:	146 x 92.9 x 10.8mm
Net Weight:	115g
Interface:	USB-C

Technical Specifications

Wireless Connection:	2.4G
Ergonomics:	Support left and right hands
Communication Distance:	5-10m (depending on the use environment)
Press Keys:	18 Press Keys+Dial

OS Compatibility

Windows 7 or later
macOS 10.12 or later